



























交換部品	型號	規格
	FX 8805-01	烙鐵筆 65 W (26 V) 帶 B 型
	A1560	加熱器 65 W (26 V)
	B5122	烙鐵管
	B2022	黑色護套
	B 5125	烙鐵筆識別套
	FH801-81	烙鐵架
	A1519	清潔海綿/色
	A1561	清潔線

	FX8801-01	烙鐵筆65 W (26 V) 帶 B 型
	FX 8802-01	氮氣烙鐵筆(26V) 帶 B 型
	FX 8803-04	出錫烙鐵65 W (26 V) 3 C 型
	FX 8804-04	電熱錫子65 W (26 V) , 2 L 型
	FX 8805-01	烙鐵筆 65 W (26 V) 帶 B 型
	C1437	出錫烙鐵架 FX-8803 用
	FH 800 - 04 BY	烙鐵架 FX-8804 用
	FR4101-81	吸錫槍本體 FR-4101140 W (24 V)
	FH410-81	吸錫槍架<清潔海綿>

	A5028	加熱器 140 W (24 V)
	A5045	陶瓷紙過濾器 L (10 片/包)※A1033 替代品。
	A5020	陶瓷紙過濾器(10 片/包)
	B5185	過濾管組件陶瓷紙過濾器※B5105 替代品。
	B5104	預過濾器
	B5102	螺母
	B5103	保護外管套
	A1013	泵隔膜(2 片/包)
	A1014	泵氣閥膜(2 片/包)

	A5030	前套筒座
	A5031	後過濾器支架
	A1519	清潔海綿黃色
	B1087	清潔針 φ 1.0 mm
	B1215	加熱器清潔針
	B1303	清潔鑽頭通針 Φ 1.0mm
	B1306	清潔鑽頭通針 φ 0.8 / 1.0 mm
	B1309	鑽頭 φ 1.0 mm
	B5106	扳手

	C5030	工具箱盒
	B2387	電源線
	B2874	清潔針 $\Phi 0.6$ mm
	B1086	清潔針 $\varphi 0.8$ mm
	B1088	清潔針 $\Phi 1.3$ mm
	B1089	清潔針 $\varphi 1.6$ mm
	B5141	清潔鑽頭通針 $\Phi 0.6$ mm
	B1302	清潔鑽頭通針 $\varphi 0.8$ mm
	B1304	清潔鑽頭通針 $\Phi 1.3$ mm

	B1305	清潔鑽頭通針 Φ 1.6 mm
	B5143	鑽頭 Φ 0.6 mm
	B1308	鑽頭 φ 0.8 mm
	B1310	鑽頭 φ 1.3mm
	B1311	鑽頭 φ 1.6 mm
	FH410-82	吸錫槍架<帶清潔絲>
	599-029	清潔絲

百電企業有限公司