


























交換部品	型號	規格
	A1438	Φ7.6 mm 吸附墊
	A 1439	Φ5 mm 吸附墊
	A1520	Φ3 mm 吸附墊
	B3023	真空管調節旋鈕（大）帶螺絲
	B5041	電源線
	B 5048	固定架
	B 2300	耐熱墊
	A 5005	加熱器組裝雲母，帶保護套
	B 5045	外管套
	B 5049	包括雲母保護套

	B 5126	固定支架組件
	C5027	PCB 板架
	B 5098	異型夾具
	B 5139	PCB 板支撐架
	B 5137	橡膠腳墊
	C5028	M 型支架
	C5029	L 型支架
	A 5027	滑動齒輪
	B 5138	帶定位旋鈕
	B 5139	托盤
	B 5140	托盤組件

	B 5128	熱電偶 0.2 mm 連接線
	B 5129	USB 傳輸線 1 米
	C5013	底部加熱器僅適用於 FR-811
	A 5003	加熱器 FR-870B / FR-872 / C5013 用